

## Supplementary Instructions for Ford Ranger Wildtrak Armadillo Roll Top Cover

Before installing your Wildtrak Armadillo Cover, you will need to identify which type of Sports bar is installed on your vehicle.



Fig1. Pre 2018 Model. Has access panels in the front corners.



Use this style of bracket (Supplied)



**Follow the  
instructions supplied  
with the cover.**



Fig2. 2018 Model onwards. Has no access panels in the front corners.



Use this style of bracket (Supplied)



**Follow the instructions  
on Page 2**



### Step 1.

Trim the canister as shown below, removing the extended section on each side.



### Step 2.

Install the included revised brackets as shown below. Remove the foremost T40 Torx screw from the plastic bracket and use it to affix the bracket. Use the supplied hex-headed screw in the rearwards hole to attach the bracket to the vehicle with a 13mm socket. **Continue with installation as per the usual instructions.**

